

## **STREET STOCK MIDSIZE FWD RULES**

**These rules are plain and simple, cut and dry!!! What is said below is exactly what you can do and nothing else. Don't try and do anything else cause most likely you will just be loaded!**

**(FWD CARS ONLY) 4 or 6 cyl cars only! 110 wheelbase and under!**

Car must be stripped of all internals and outside plastic as well as all windows. Dash may stay in the car.

Roof Sign Required

### **FRAMES:**

**NO welding on frames or holes whatsoever.**

**If there is not a hole in frame to inspect inside a 1 inch hole must be applied behind bumper shock. A 1 inch washer may be welded around hole.**

**If no hole we will have a 3/8 drill bit to make a hole for inspection. If you do not allow us to drill car goes on the trailer.**

### **CAGE**

Full 4 point cage MUST be applied to your car for drivers safety must be floating. 2 down bars allowed 1 down bar per side can be ran from cage to floor and bolted to floor between the front door seams.

Tank can be mounted to back of cage bar or bolted through floor (32 inches wide). Must have 2 inch gap between protector and speaker deck. IF IN FRONT OF REAR AXLE CAN BE LEFT UNDER CAR.

1 front windshield bars must be added. 9 wire, 2x2 straps, chain

## **SUSPENSION**

100 % stock suspension.

2 inch's of bounce in struts

**NOTHING can be welded to the strut!**

## **DOORS, HOOD, TRUNK**

Drivers door may be welded shut. Every other seam can have

3 spots of 9 Wire double wrapped

3/8 chain

2x2 plates.

Hood and Trunk must have 12x12 hole in them.

No duck tape on doors

## **Front body/subframe mounting area**

**2** all thread may run through your front body mount up through hood to secure hood. No bigger than **1 in** all thread.

**2** extra **6 inch** long bolts may be welded to strut tower to secure hood. **1 in** max or 9 wire.

Front subframe may not be welded to body!

**NO Strut blocks**

**NO extra body mounts**

## **BUMPERS**

Factory Car bumper stuffed. (NO Chrysler Pointys)

A **4x4 ¼ inch tube** may be used for a bumper that is it. **(NO HOMEADE POINTS)**

You may use a **6 inch piece of 3x3 tube** or **6x3x¼ flat steel** starting at bumper to mount bumper so bumper does not fall off. **Nothing else.**

## **TIRES**

May run any tire on the front.

Rears must be donuts or forklifts.

### **MISC**

CARB CONVERSIONS are ok! No protectors of any kind

Motor must be from factory to that car. No swapping.

Aftermarket steering, peddles, shifters, Headers can be used.